


LC1 F115...F1250

www.schneider-electric.com



LC1 F115
LC1 F185
LC1 F225
LC1 F285
LC1 F330

LC1 F400
LC1 F500

LC1 F630
LC1 F800

For Motor Starting Use Schneider Electric Overload Relay, Series LR

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Read and follow all instructions.
Failure to follow these instructions may result in death or serious injury.

RISCHIO DI SCARICA ELETTRICA, ESPLOSIONE O ARC FLASH

Leggere attentamente tutte le istruzioni.
Se non si seguono queste istruzioni possono provocare lesioni gravi e inclusa la morte.

RISCO DE ELECTROCUTION, DE EXPLOSION O DE ARCO ELÉCTRICO

Leer cuidadosamente todas las instrucciones.
Si no se siguen estas instrucciones pueden producirse lesiones graves e incluso la muerte.

RISQUE D'ELECTROCUTION, D'EXPLOSION OU D'ARC ÉLECTRIQUE

Lisez attentivement toutes les instructions.
Le non respect de ces instructions peut entraîner la mort ou de graves blessures.

GEFAHR VON ELEKTROSCHLAG, EXPLOSION ODER ARC FLASH

Lesen Sie alle Anweisungen sorgfältig.
Die Nichtbefolgung dieser Anweisungen führt zu Tod oder schweren Verletzungen.

RISCO DE ELECTROCUTION, DE EXPLOSION OU DE ARCO ELÉCTRICO

Leia atentamente todas as instruções.
O não cumprimento destas instruções pode provocar lesões graves e inclusive a morte.



www.schneider-electric.com
1-800-552-5525
1-800-552-5525
1-800-552-5525

Schneider Electric Industries SAS
25 rue Joseph Monier
92000 Nanterre Cedex
France
F - 92500 Nanterre Cedex
www.schneider-electric.com



W9 1355817 0191 19

19/20