


## Install the Chassis Interconnect Cable (optional)


To connect up to three SLC 500 chassis together, install the chassis interconnect cable before installing the power supply.




For more information, see the SLC 500 Modular Hardware Style User Manual, publication 1747-UM011.

## Power Supply Installation

1. Align the circuit board of the power supply with the card guides on the left side of the chassis.



2. Slide the power supply in until it is flush with the chassis. Then fasten the power supply to the chassis.



Use these screws to fasten the power supply to the chassis with 1.2 Nm (11 lb-in) torque, max.